



Rain Guard For Injen Evolution Intake System P/N:EVO2000 Sold seperately

Part number
EVO2000RG
Rain Guard
2013-2017
Scion/Subaru/Toyota
FRS/BRZ/86
2.0L Boxer 4 Cyl.

- | | |
|------------------------|---------|
| 1- Rain shield Guard | X-20125 |
| 2- M6 Socket cap screw | (#6083) |
| 2- 3/8" vinyl cap | (#8005) |
| 1- 1 page instruction | |

Congratulations! You have just purchased The Injen Evolution Intake System.

Please check the contents of this box immediately.

Report any defective or missing parts to the Authorized Injen Technology dealer you purchased this product from. Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the dealer you purchased this product from. Installation DOES require some mechanical skills. A qualified mechanic is always recommended.

*Do not attempt to install the intake system while the engine is hot. The installation may require removal of radiator fluid line that may be hot.

Injen Technology offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.

Injen Technology 244 Pioneer Place Pomona, CA 91768 USA

Please check the contents of this box immediately.



WARNING: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE SYSTEM, ENGINE AND COMPONENTS!!!

***Do not attempt to install the intake system while the engine is hot.**

Severe burn could result from touching hot engine components!

Caution: The installation of this rain guard does not protect the engine from ingesting water during heavy rain fall or floods. The rain guard will help deflect direct rain from entering the Injen Ram Air inlet during light rain fall. Injen Technology Ram Air Intake Systems should be removed in wet climate conditions. Failure to comply with the above warning may cause water to be absorbed into the engine through the Intake System causing serious engine failure. Injen Technology assumes no liability for damages to your engine due to water entering your engine through the Injen Technology Intake System.



Remove front bumper cover. Loosen and remove the injen Evolution intake out of vehicle. Loosen the radiator support. (see injen Evolution instruction sheet EVO2000) Loosen the 2 socket cap screws from bracket and 2 plastic push clips. Push Injen ram scoop down allowing for access to inserts on scoop.



Install the rain guard. Secure using provided M6 socket cap screws and tighten. Once secure, cover the socket cap screw using provided vinyl cap. This will prevent any contact with screws and front bumper support. Failure to do so will result in vibration noise.



Rain guard installation is now complete. Re-install the the scoop assembly and secure the intake system. **Note: Check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.**