




EXPLODED VIEW



Vehicle Application:			
Make: Dodge			
Model: Ram 2500/3500			
Year: 2003-2007.5			
Engine: 5.9L Cummins Turbo Diesel			

Item	QTY.	P/N	Description
A	1	#15047	Dodge Rotomold tube
B	1	#15045	Dodge Rotomold Plenum
C	1	#15046	Dodge Rotomold Box
D	1	#1125	6.00" Filter
E	1	#3129	4.00" Straight Hose
F	1	#3200	4.50" Hump Hose
G	2	#4014	#72 Clamps
H	1	#6111	Filter Minder Plug
I	2	#6072	M4X16mm Button Head Bolts
J	1	#6095	M6X80mm Bolt
K	3	#6096	M6X30mm Bolts
N	2	#4006	#64 Clamps
M	4	#8047	1/2"OD rubber seal washer

TOOLS REQUIRED	
• 10mm Ratchet & Socket	
• 8mm nut drive	
• Allen key	
• 7mm nut driver	
• Screw driver	

WARNING: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE SYSTEM, ENGINE AND COMPONENTS!!!
***Do not attempt to install the intake system while the engine is hot.**
 Severe burn could result from touching hot engine components!

Report any defective or missing parts to the authorized Injen dealer you purchased this product from. Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation, please contact your Injen Technology dealer. Installation DOES require some mechanical skills. A qualified mechanic is always recommended.

A Limited Lifetime Warranty to the original purchaser against defects in material and workmanship on all Injen intake systems excluding the filter element. Any and all warranty coverage is limited to the repair or replacement of the defective part only, at Injen Technology's discretion. The warranty does not cover incidental or consequential damages, nor does it cover the cost of installation or removal of the defective part or its replacement. Proof of purchase is required.

Instruction Manual P/N:EVO8004

NOTE: This intake kit may not work on vehicles with the following aftermarket modifications.

- Aftermarket Intercooler piping
- Aftermarket intercooler
- Turbo upgrade
- Modified body panels
- Suspension & Chassis modifications

The SuperNano-Web filter media is a dry synthetic media that outperforms the competition. The media itself is a proprietary base blend of synthetics and cellulose. Cellulose fibers are larger than synthetic fibers, and have larger spaces between the fibers, causing contaminants to load in the depth of the media and plug the airflow path. This creates higher restriction levels and less capacity. The synthetic fibers in the SuperNano-Web media are submicron in diameter and have small interior fiber spaces, which result in more contaminants being captured on the surface of the media. This can help keep restriction levels low as the filter loads with dirt and containments



**A New Generation of Filters
Designed to perform and
filter like no other**

INJEN SuperNano-Web Technology

Existing media without
Injen SuperNano-Web Technology

Superior Injen
SuperNano-Web Technology

If you look at the picture to the left, you can see the Nano-fiber web on top of our base media. That web, or Super-Nano-Web as we like to call it, helps trap smaller particles and protect your engine.

To Clean your filter:

Carefully remove the filter from the housing. Once removed, wipe down the housing using a clean shop towel, being careful not to knock any dirt and/or debris in the air inlet. Your filters can be cleaned by carefully vacuuming the filter media from the dirty side, or by holding the filter with one hand and carefully blowing the filter media at a 45-degree angle from the clean side using low-pressure shop air (15-20 lbs. psi).

****IT IS IMPORTANT TO NOT USE ANY CLEANERS ON THE SUPERNANO-WEB MEDIA OR APPLY ANY OIL!!!***

Note:


The C.A.R.B. Exempt sticker must be attached under the hood in a manner that is easily viewed by an emissions inspector.

NOTE: DISCONNECT BATTERY BEFORE INSTALLATION!!!

Instruction Manual P/N:EVO8004



1. Stock intake system shown.



2. Use a 10mm socket/ratchet and remove the 10mm nut securing the stock air box assembly to the radiator support.



3. Disconnect the AIT sensor harness and then remove the two 7mm screws to remove the AIT sensor from the stock air box assembly



4. Loosen the clamp on the stock air box assembly air duct to the turbocharger




5. Pull the air duct off the turbocharger and then firmly lift up on the entire air box assembly and remove the entire stock air box assembly from the engine bay



6. Place the 4.00" straight hose and two #72 clamps onto the turbocharger inlet



7. Place the AIT sensor into the Injen intake tube and two M4X16 bolts to secure it to the tube with an allen key.



8. Drop the Injen intake box into the OE air box location. Line up the two mounting taps underneath the Injen air box to the two factory mounting grommets.



9. Once the Injen air box is mounted, use the factory 10mm bolt to secure the air box bracket to the radiator support.



10. Place the supplied Filter Monitor Plug into the lower air box assembly.



11. Place the filter onto the 6.00" opening on the intake plenum and then secure the clamp.



12. Place the three M8X25mm bolts and one M8X80mm bolt to the top of the plenum illustrated by the photo and then secure the allen bolts



13. Place the 4.50" hump hose and two #72 clamps onto the 4.50" end of the Injen intake tube. Make sure you slide the hump hose as far back as you can.




14. Drop the Injen intake tube into the engine bay.



15. Connect the lower part of the Injen tube to the 4.00" coupler on the turbocharger inlet. Then connect the top of the tube to the plenum and slide the 4.50" hump hose over and secure all clamps.



16. Re-connect the the AIT sensor. Your installation is now complete. Go over all clamps and bolts to make sure they are all secure.



Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose. Note: Check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.

Test Drive:

1. With the transmission in neutral or park and the parking brake engaged, start the engine. Listen for air leaks or odd noises. If air leaks are detected, secure hoses and connections. For any odd noises, inspect entire system for cause and adjust intake as needed. The Injen intake will function identically to the factory system but will be louder and more powerful.
2. Perform a road test. Listen for odd noises or rattles and fix as necessary.
3. If there are no issues, continue to enjoy your added performance from the Injen performance Intake kit.
4. Injen Technology recommends you periodically check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.

1. Upon completion of the installation, reconnect the negative battery terminal before you start the engine.
2. Align the entire intake system for the best possible fit. Once the intake has been properly fitted continue to tighten all nuts, bolts and clamps.
3. Periodically, recheck the alignment of the intake system and make sure there is proper clearance around and along the length of the intake. Failure to follow proper maintenance procedures may cause damage to the intake and will void the warranty.
4. Start the engine and listen carefully for any odd noises, rattles and/or air leaks prior to taking it for a test drive. If any problems arise go back and check the vacuum lines, hoses and clamps that maybe causing leaks or rattles and correct the problem.
5. Check the filter for excessive dirt build up. Clean or replace the filter with an original Injen filter (can be bought on-line at "injenonline.com"). Congratulations! You have just completed the installation of the best intake system sold on the market. Enjoy the added power and performance of your new intake system.