



Part number IS2080
2000-2002 Toyota Corolla S
1.8L

- 1- Air intake system (SR)
- 1- **2 3/4" Injen filter (#1013)**
- 1- 2 1/2" straight hose (#3048)
- 2- Power-Bands (.312)(.040) (#4003)
- 1- m6 vibra-mount (#6020)
- 2- m6 flange nut (#6002)
- 1- m6 x m16 bolt (#6005)
- 3- Fender washer (#6010)
- 1- 1/2" 12mm sensor stub(red) (#3066)
- 1- Instruction

Congratulations! You have just purchased the best engineered, dyno-proven intake system available.

Please check the contents of this box immediately.

Report any defective or missing parts to the Authorized Injen Technology dealer you purchased this product from.

Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the dealer you purchased this product from.

Installation DOES require some mechanical skills. A qualified mechanic is always recommended.

*Do not attempt to install the intake system while the engine is hot.

The installation may require removal of radiator fluid line that may be hot.


Injen Technology offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.

Injen Technology 244 Pioneer Place Pomona, CA 91768 USA

Please check the contents of this box immediately.

Note: This intake system was Dyno-tested with an Injen filter and Injen parts the use of any other filter or part will void the warranty and CARB exemption number.

Parts and accessories are available on line at "Injenonline.com"






Figure 2




Figure 3



Figure 4




Figure 5




Figure 6

Note: Disconnect the battery terminals before starting this installation

- 1- Remove air intake box and air intake duct going to the throttle body. Remove the air temperature control sensor, the blue vacuum switching valve and the OBD canister to be installed later in the instructions.
- 2- Place the 2 1/2" straight hose onto the throttle body, use 2 clamps as seen in figure 2 and tighten the clamp on the throttle body.
- 3- Install the vibra-mount onto the stock location of the air box as seen in figure 3 and 6, you will also want to place the 10mm nut and washer in place as seen.
- 4- Relocate the black diagnostic sensor box as seen in figure 6 and use the stock 6mm bolt to fasten. Make sure you run the black wire harness underneath the intake when installed.
- 5- Take the one piece intake and place in position as seen in figures 1 and 6. Slip the 90 degree end into the throttle body straight hose and align the bracket to the vibra-mount until you find the best fit.
- 6- Before you tighten the clamps and nuts you may want to place the red Injen filter on the end as seen in figures 1 and 6. Continue to align in place then tighten all nuts, bolts and clamps.
- 7- Take the 6mm nut, bolt and 2 washers, bolt the vacuum switching valve to the bracket on the intake as seen in figure 5 and fasten tight.
- 8- Press the 12mm sensor stub into the 3/4" port on the intake. Now press the OBD canister port into the stub as seen in figures 5 and 6.
- 9- Insert the air temperature control into the CNC machined bracket on the intake and use the stock screws to fasten in place as seen in figure 4.
- 10- Check the alignment for best fit and tighten all nuts, bolts and clamps when there is proper clearance through -out the intake and filter.
- 11- Reconnect the battery terminals and remove all tools and rags from the engine compartment before starting your engine.
- 12- Congratulations! you have just completed this installation.